



Replacing a Battery Box in a Two Burner Drop In

1. Remove the cooking grill, large flame spreader and knobs
2. Remove the control panel by unscrewing the two screws on either side
3. Unscrew the screws holding the sink panel and remove
4. Unclip the wires connected to the battery box
5. Remove the old battery box by undoing the 2 nuts holding it to the base.
6. Undo the nuts holding the bracket to the old battery box and re-assemble to the new one
7. Reconnect the wires to the battery box. Red ones go to the bottom 2 tabs and white ones to the top two
8. Re-attach the battery box to the unit by placing the bracket holes over the studs and securing the nuts
9. Replace the sink, control panel and secure
10. Replace the knobs, large flame spreader and cooking grill