



Replacing a Battery Box in a Mediterranean or Caribbean

1. Remove the door assembly by undoing the 2 ¼-20 acorn nuts at the bottom
2. Locate the battery box to be replaced. Caribbean is Broiler/Oven – Left, Top burners – right. Mediterranean is Broiler/Oven - Left, small burners – Middle, large burner – Right
3. Disconnect the wires – Make note of which wires went where.
4. Undo the nuts on either side on the battery box and remove.
5. Place the new battery box onto mounting studs and secure.
6. Replace the wires to their proper positions.
7. Replace the door assembly